

Work-Driven Design®

DURABILITY DELIVERED.

Safe, strong, and ready to go to work.

Utilimaster truck bodies are built tough from the chassis up, setting the highest standard for heavy-duty commercial delivery. Built and assembled across North America with the most durable materials available, from aluminum to Utiliplate[®] sidewalls, they're ready to deliver unmatched performance and reliability for every route, every time.

Lasting quality takes you further down the road.

For more than 50 years, Utilimaster has delivered success to small and large fleets with long-lasting vehicles of all shapes and sizes. Designed, engineered, and purpose-built to get every job done with speed, safety, and efficiency – just like the men and women that drive them.



Peace of mind. Utilimaster builds reliable truck bodies, backed by an industry leading warranty.

Key Features



Rugged Utiliplate[™] sidewalls are resilient, lightweight, and long-lasting.



Low step-in heights on side door for easy cab entry and exit.



Cargo management with wall and floor mount options keeps cargo safely secured.



Lift gate options make light work of loading cargo.

Specifications

Chassis	Available Lengths	Height	Body Width
Ford	12' 14' 16' 18' 20' 22' 24' 26' 30'	72" - 108"	96" 102'
Chevy	12' 14' 16' 18' 20' 22' 24' 26'	72" - 108"	96" 102'
Dodge	12' 14' 16' 18' 20'	72" - 108"	96" 102'
International	16' 18' 20' 22' 24' 26' 30'	72" - 108"	96" 102'
Freightliner	16' 18' 20' 22' 24' 26' 30'	72" - 108"	96" 102'
lsuzu	16' 18' 20' 22' 24' 26' 30'	72" - 108"	96" 102'
Peterbilt / Kenworth	16' 18' 20' 22' 24' 26' 30'	72" - 108"	96" 102'
Hino	16' 18' 20' 22' 24' 26' 30'	72" - 108"	96" 102'
Mitsubishi	16' 18' 20'	72" - 108"	96" 102'
Mack	16' 18' 20' 22' 24' 26' 30'	72" - 108"	96" 102'

Features/Options



Aluminum or Utiliplate® sidewalls



Advanced safety packages



Side-doors with low step-in height



Wide variety of lift gates



Cargo management

 (\mathbf{R})

Let's work together to meet your needs.

BLUEARC

UTILIMASTER

Our dedicated team of professionals are ready to work with you and your customers to design and build walk-in vans that stand the test of time. To see how our proven Work-Driven Design[®] process can work best for you, contact Utilimaster today.

Get Started 800.582.0079 utilimaster.com/products/walk-in-van | Find Aftermarket Options 800.237.7806 amparts.utilimaster.com

DURA MAG

MAGNUM

F

BUILTMORE

ÍTÚ

